GE Refrigerator Guide 2026

The **Universal Shabbos Keeper Version 5.0** is designed for selected GE models, primarily those manufactured after 2018, to ensure full Shabbos compliance. It disables key electronic functions that cannot be controlled manually or through a standard built-in Shabbos Mode.

Please review the guidelines below to understand how your model is affected.

★ Model Compatibility

Compatible Models

All models listed below are compatible with the Universal Shabbos Keeper or can be used on Shabbos.

Technical Issues

No special updates are typically required for a new fridge. If you experience any technical issues, please contact us for support as soon as you notice a concern.

Models Marked with an Asterisk (*)

- Top Freezer models marked with an asterisk (*) are not compatible with the Shabbos Keeper.
- If manufactured after 2023, these models include a built-in Shabbos Mode approved by the OU.
- You can find the OU logo on the model tag.
- For these models, Shabbos Mode must be activated manually before each Shabbos and Yom Tov.

★ Upgrading an Existing Refrigerator

If you already own a GE refrigerator and are considering adding a Shabbos Keeper, please contact us. We will confirm whether your appliance can be updated to ensure compatibility with the Shabbos Keeper.

★ Key Features

100% Shabbos Compliance

The Shabbos Keeper is the only halachically certified device for refrigerators that ensures full Shabbos compliance. It deactivates critical functions, including lights, fans, sensors, and the compressor, and switches the appliance to a timed cycle using an Enhanced Shabbos Mode (EHM).

Automatic Activation

Automatically activates Shabbos Mode around 90 minutes before each Shabbos and Yom Tov - no weekly user input required.

Rabbinic Endorsements

Certified, endorsed, and recommended by OU, CRC, and HalachaTech USA.

★ Ice Maker Guidelines

Automatically Disabled with Shabbos Keeper

If your model falls under this category, the Shabbos Keeper automatically disables the ice maker.

No manual action is needed before Shabbos.

Required to Manually Disable Icemaker

For these models, the Shabbos Keeper does not control the ice maker. • You must manually turn off the icemaker before Shabbos, even if you don't plan to use it. Leaving it on may cause it to be activated when the door is opened, which can lead to halachic concerns.

Required to Disable Icemaker when Planning to Take Ice

For these models, the Shabbos Keeper does not connect to the icemaker.

If you plan to retrieve ice on Shabbos, disable the icemaker beforehand to prevent it from refilling.

If you do not plan to use it, you may leave it on; it will only be activated if ice is removed.

★ Contact Us

For halachic questions, technical support, or help with compatibility, please contact us:

Email: Support@ZmanTechnologies.com

Phone: 855-381-0977 extension #4

Model Number:	Product Type:	Width:	How can this fridge be used on Shabbos?	Ice maker Deactivation Status
GDE21DGK	2-door Bottom Freezer	30"	Shabbos Keeper	Required to Disable Icemaker
GDE21DMK	2-door Bottom Freezer	30"	Shabbos Keeper	Required to Disable Icemaker
GDE21DSK	2-door Bottom Freezer	30"	Shabbos Keeper	Required to Disable Icemaker
GDE21DYR	2-door Bottom Freezer	30"	Shabbos Keeper	Required to Disable Icemaker
GDE21EGK	2-door Bottom Freezer	30"	Shabbos Keeper	Required to Disable Icemaker
GDE21EMK	2-door Bottom Freezer	30"	Shabbos Keeper	Required to Disable Icemaker
GDE21ESK	2-door Bottom Freezer	30"	Shabbos Keeper	Required to Disable Icemaker
GDE21EYK	2-door Bottom Freezer	30"	Shabbos Keeper	Required to Disable Icemaker
GDE25EGK	2-door Bottom Freezer	33"	Shabbos Keeper	Required to Disable Icemaker
GDE25ESK	2-door Bottom Freezer	33"	Shabbos Keeper	Required to Disable Icemaker
GDE25EYK	2-door Bottom Freezer	33"	Shabbos Keeper	Required to Disable Icemaker
PDE21KGK	2-door Bottom Freezer	30"	Shabbos Keeper	Required to Disable Icemaker
PDE21KMK	2-door Bottom Freezer	30"	Shabbos Keeper	Required to Disable Icemaker
PDE21KSK	2-door Bottom Freezer	30"	Shabbos Keeper	Required to Disable Icemaker
CFE24SSK	3-door Bottom Freezer	33"	Shabbos Keeper	Required to Disable Ice maker when planning to Take Ice
CFE26KP2	3-door Bottom Freezer	36"	Shabbos Keeper	Required to Disable Icemaker when Planning to Take Ice

Model Number:	Product Type:	Width:	How can this fridge be used on Shabbos?	Ice maker Deactivation Status
CFE28TP2	3-door Bottom Freezer	36"	Shabbos Keeper	Automatically Disabled with Shabbos Keeper
CFE28TP3	3-door Bottom Freezer	36"	Shabbos Keeper	Automatically Disabled with Shabbos Keeper
CFE28TP4	3-door Bottom Freezer	36"	Shabbos Keeper	Automatically Disabled with Shabbos Keeper
CFE28TSH	3-door Bottom Freezer	36"	Shabbos Keeper	Automatically Disabled with Shabbos Keeper
CFE28UEL	3-door Bottom Freezer	36"	Shabbos Keeper	Automatically Disabled with Shabbos Keeper
CFE28UP2	3-door Bottom Freezer	36"	Shabbos Keeper	Automatically Disabled with Shabbos Keeper
CFE28UP3	3-door Bottom Freezer	36"	Shabbos Keeper	Automatically Disabled with Shabbos Keeper
CFE28USH	3-door Bottom Freezer	36"	Shabbos Keeper	Automatically Disabled with Shabbos Keeper
CNE25SSK	3-door Bottom Freezer	33"	Shabbos Keeper	Required to Disable Icemaker
CWE19SP2	3-door Bottom Freezer	33"	Shabbos Keeper	Required to Disable Icemaker
CWE19SP3	3-door Bottom Freezer	33"	Shabbos Keeper	Required to Disable Icemaker
CWE19SP4	3-door Bottom Freezer	33"	Shabbos Keeper	Required to Disable Icemaker
CWE23SP2	3-door Bottom Freezer	36"	Shabbos Keeper	Automatically Disabled with Shabbos Keeper
CWE23SP3	3-door Bottom Freezer	36"	Shabbos Keeper	Automatically Disabled with Shabbos Keeper
CWE23SP4	3-door Bottom Freezer	36"	Shabbos Keeper	Automatically Disabled with Shabbos Keeper
CWE23SSH	3-door Bottom Freezer	36"	Shabbos Keeper	Automatically Disabled with Shabbos Keeper
CYE22TP2	3-door Bottom Freezer	36"	Shabbos Keeper	Automatically Disabled with Shabbos Keeper

Model Number:	Product Type:	Width:	How can this fridge be used on Shabbos?	Ice maker Deactivation Status
CYE22TP3	3-door Bottom Freezer	36"	Shabbos Keeper	Automatically Disabled with Shabbos Keeper
CYE22TP4	3-door Bottom Freezer	36"	Shabbos Keeper	Automatically Disabled with Shabbos Keeper
CYE22TSH	3-door Bottom Freezer	36"	Shabbos Keeper	Automatically Disabled with Shabbos Keeper
CYE22UEL	3-door Bottom Freezer	36"	Shabbos Keeper	Automatically Disabled with Shabbos Keeper
CYE22UP2	3-door Bottom Freezer	36"	Shabbos Keeper	Automatically Disabled with Shabbos Keeper
CYE22UP3	3-door Bottom Freezer	36"	Shabbos Keeper	Automatically Disabled with Shabbos Keeper
CYE22USH	3-door Bottom Freezer	36"	Shabbos Keeper	Automatically Disabled with Shabbos Keeper
DFE24JYR	3-door Bottom Freezer	33"	Shabbos Keeper	Required to Disable Icemaker when Planning to Take Ice
DFE28JBL	3-door Bottom Freezer	36"	Shabbos Keeper	Automatically Disabled with Shabbos Keeper
DFE28JEL	3-door Bottom Freezer	36"	Shabbos Keeper	Automatically Disabled with Shabbos Keeper
DFE28JMK	3-door Bottom Freezer	36"	Shabbos Keeper	Automatically Disabled with Shabbos Keeper
DFE28JSK	3-door Bottom Freezer	36"	Shabbos Keeper	Automatically Disabled with Shabbos Keeper
GFD28GBL	3-door Bottom Freezer	36"	Shabbos Keeper	Automatically Disabled with Shabbos Keeper
GFD28GEL	3-door Bottom Freezer	36"	Shabbos Keeper	Automatically Disabled with Shabbos Keeper
GFD28GML	3-door Bottom Freezer	36"	Shabbos Keeper	Automatically Disabled with Shabbos Keeper
GFD28GSL	3-door Bottom Freezer	36"	Shabbos Keeper	Automatically Disabled with Shabbos Keeper

Model Number:	Product Type:	Width:	How can this fridge be used on Shabbos?	Ice maker Deactivation Status
GFD28GYN	3-door Bottom Freezer	36"	Shabbos Keeper	Automatically Disabled with Shabbos Keeper
GFE24JBL	3-door Bottom Freezer	33"	Shabbos Keeper	Required to Disable Icemaker when Planning to Take Ice
GFE24JGK	3-door Bottom Freezer	33"	Shabbos Keeper	Required to Disable Icemaker when Planning to Take Ice
GFE24JMK	3-door Bottom Freezer	33"	Shabbos Keeper	Required to Disable Icemaker when Planning to Take Ice
GFE24JSK	3-door Bottom Freezer	33"	Shabbos Keeper	Required to Disable Ice maker when planning to Take Ice
GFE24JYK	3-door Bottom Freezer	33"	Shabbos Keeper	Required to Disable Ice maker when planning to Take Ice
GFE26GGK	3-door Bottom Freezer	36"	Shabbos Keeper	Automatically Disabled with Shabbos Keeper
GFE26GMK	3-door Bottom Freezer	36"	Shabbos Keeper	Automatically Disabled with Shabbos Keeper
GFE26GSK	3-door Bottom Freezer	36"	Shabbos Keeper	Automatically Disabled with Shabbos Keeper
GFE26JBM	3-door Bottom Freezer	36"	Shabbos Keeper	Required to Disable Icemaker when Planning to Take Ice
GFE26JEM	3-door Bottom Freezer	36"	Shabbos Keeper	Required to Disable Icemaker when Planning to Take Ice
GFE26JGM	3-door Bottom Freezer	36"	Shabbos Keeper	Required to Disable Icemaker when Planning to Take Ice
GFE26JMM	3-door Bottom Freezer	36"	Shabbos Keeper	Required to Disable Icemaker when Planning to Take Ice

Model Number:	Product Type:	Width:	How can this fridge be used on Shabbos?	Ice maker Deactivation Status
GFE26JSM	3-door Bottom Freezer	36"	Shabbos Keeper	Required to Disable Icemaker when Planning to Take Ice
GFE26JYM	3-door Bottom Freezer	36"	Shabbos Keeper	Required to Disable Icemaker when Planning to Take Ice
GFE28GBL	3-door Bottom Freezer	36"	Shabbos Keeper	Automatically Disabled with Shabbos Keeper
GFE28GEL	3-door Bottom Freezer	36"	Shabbos Keeper	Automatically Disabled with Shabbos Keeper
GFE28GGK	3-door Bottom Freezer	36"	Shabbos Keeper	Automatically Disabled with Shabbos Keeper
GFE28GMK	3-door Bottom Freezer	36"	Shabbos Keeper	Automatically Disabled with Shabbos Keeper
GFE28GSK	3-door Bottom Freezer	36"	Shabbos Keeper	Automatically Disabled with Shabbos Keeper
GFE28GYN	3-door Bottom Freezer	36"	Shabbos Keeper	Automatically Disabled with Shabbos Keeper
GFE28HMK	3-door Bottom Freezer	36"	Shabbos Keeper	Automatically Disabled with Shabbos Keeper
GFE28HSK	3-door Bottom Freezer	36"	Shabbos Keeper	Automatically Disabled with Shabbos Keeper
GFE28HYN	3-door Bottom Freezer	36"	Shabbos Keeper	Automatically Disabled with Shabbos Keeper
GFS26GMN	3-door Bottom Freezer	36"	Shabbos Keeper	Automatically Disabled with Shabbos Keeper
GFS26GSN	3-door Bottom Freezer	36"	Shabbos Keeper	Automatically Disabled with Shabbos Keeper
GNE21DGK	3-door Bottom Freezer	30"	Shabbos Keeper	Required to Disable Icemaker
GNE21DSK	3-door Bottom Freezer	30"	Shabbos Keeper	Required to Disable Icemaker
GNE21DYR	3-door Bottom Freezer	30"	Shabbos Keeper	Required to Disable Icemaker

Model Number:	Product Type:	Width:	How can this fridge be used on Shabbos?	Ice maker Deactivation Status
GNE21FMK	3-door Bottom Freezer	30"	Shabbos Keeper	Required to Disable Icemaker
GNE21FSK	3-door Bottom Freezer	30"	Shabbos Keeper	Required to Disable Icemaker
GNE21FYK	3-door Bottom Freezer	30"	Shabbos Keeper	Required to Disable Icemaker
GNE25DGK	3-door Bottom Freezer	33"	Shabbos Keeper	Required to Disable Icemaker
GNE25DSK	3-door Bottom Freezer	33"	Shabbos Keeper	Required to Disable Icemaker
GNE25DYR	3-door Bottom Freezer	33"	Shabbos Keeper	Required to Disable Icemaker
GNE25JGK	3-door Bottom Freezer	33"	Shabbos Keeper	Required to Disable Icemaker
GNE25JMK	3-door Bottom Freezer	33"	Shabbos Keeper	Required to Disable Icemaker
GNE25JSK	3-door Bottom Freezer	33"	Shabbos Keeper	Required to Disable Icemaker
GNE25JYK	3-door Bottom Freezer	33"	Shabbos Keeper	Required to Disable Icemaker
GNE27ESM	3-door Bottom Freezer	36"	Shabbos Keeper	Required to Disable Icemaker
GNE27EYM	3-door Bottom Freezer	36"	Shabbos Keeper	Required to Disable Icemaker
GNE27JGM	3-door Bottom Freezer	36"	Shabbos Keeper	Required to Disable Icemaker
GNE27JMM	3-door Bottom Freezer	36"	Shabbos Keeper	Required to Disable Icemaker
GNE27JSM	3-door Bottom Freezer	36"	Shabbos Keeper	Required to Disable Icemaker
GNE27JYM	3-door Bottom Freezer	36"	Shabbos Keeper	Required to Disable Icemaker
GNE29GGK	3-door Bottom Freezer	36"	Shabbos Keeper	Automatically Disabled with Shabbos Keeper

Model Number:	Product Type:	Width:	How can this fridge be used on Shabbos?	Ice maker Deactivation Status
GNE29GMK	3-door Bottom Freezer	36"	Shabbos Keeper	Automatically Disabled with Shabbos Keeper
GNE29GSK	3-door Bottom Freezer	36"	Shabbos Keeper	Automatically Disabled with Shabbos Keeper
GNE29GYN	3-door Bottom Freezer	36"	Shabbos Keeper	Automatically Disabled with Shabbos Keeper
GWE19JGL	3-door Bottom Freezer	33"	Shabbos Keeper	Required to Disable Icemaker
GWE19JML	3-door Bottom Freezer	33"	Shabbos Keeper	Required to Disable Icemaker
GWE19JSL	3-door Bottom Freezer	33"	Shabbos Keeper	Required to Disable Icemaker
GWE19JYL	3-door Bottom Freezer	33"	Shabbos Keeper	Required to Disable Icemaker
GWE22JYM	3-door Bottom Freezer	36"	Shabbos Keeper	Required to Disable Icemaker
GWE23GEN	3-door Bottom Freezer	36"	Shabbos Keeper	Automatically Disabled with Shabbos Keeper
GWE23GMN	3-door Bottom Freezer	36"	Shabbos Keeper	Automatically Disabled with Shabbos Keeper
GWE23GYN	3-door Bottom Freezer	36"	Shabbos Keeper	Automatically Disabled with Shabbos Keeper
GYE18JBL	3-door Bottom Freezer	33"	Shabbos Keeper	Required to Disable Icemaker when Planning to Take Ice
GYE18JEM	3-door Bottom Freezer	33"	Shabbos Keeper	Required to Disable Icemaker when Planning to Take Ice
GYE18JML	3-door Bottom Freezer	33"	Shabbos Keeper	Required to Disable Icemaker when Planning to Take Ice
GYE18JSL	3-door Bottom Freezer	33"	Shabbos Keeper	Required to Disable Icemaker when Planning to Take Ice

Model Number:	Product Type:	Width:	How can this fridge be used on Shabbos?	Ice maker Deactivation Status
GYE18JYL	3-door Bottom Freezer	33"	Shabbos Keeper	Required to Disable Icemaker when Planning to Take Ice
GYE21JYM	3-door Bottom Freezer	36"	Shabbos Keeper	Required to Disable Icemaker when Planning to Take Ice
GYE22GEN	3-door Bottom Freezer	36"	Shabbos Keeper	Automatically Disabled with Shabbos Keeper
GYE22GMN	3-door Bottom Freezer	36"	Shabbos Keeper	Automatically Disabled with Shabbos Keeper
GYE22GYN	3-door Bottom Freezer	36"	Shabbos Keeper	Automatically Disabled with Shabbos Keeper
GYE22HBL	3-door Bottom Freezer	36"	Shabbos Keeper	Automatically Disabled with Shabbos Keeper
GYE22HMK	3-door Bottom Freezer	36"	Shabbos Keeper	Automatically Disabled with Shabbos Keeper
GYE22HSK	3-door Bottom Freezer	36"	Shabbos Keeper	Automatically Disabled with Shabbos Keeper
GYE22HYN	3-door Bottom Freezer	36"	Shabbos Keeper	Automatically Disabled with Shabbos Keeper
GYS22GMN	3-door Bottom Freezer	36"	Shabbos Keeper	Automatically Disabled with Shabbos Keeper
GYS22GSN	3-door Bottom Freezer	36"	Shabbos Keeper	Automatically Disabled with Shabbos Keeper
NNE21DSM	3-door Bottom Freezer	30"	Shabbos Keeper	Required to Disable Icemaker
PFD28KBL	3-door Bottom Freezer	36"	Shabbos Keeper	Automatically Disabled with Shabbos Keeper
PFD28KSL	3-door Bottom Freezer	36"	Shabbos Keeper	Automatically Disabled with Shabbos Keeper
PFD28KYN	3-door Bottom Freezer	36"	Shabbos Keeper	Automatically Disabled with Shabbos Keeper
PFE24HBM	3-door Bottom Freezer	33"	Shabbos Keeper	Required to Disable Icemaker when Planning to Take Ice

Model Number:	Product Type:	Width:	How can this fridge be used on Shabbos?	Ice maker Deactivation Status
PFE24HGL	3-door Bottom Freezer	33"	Shabbos Keeper	Required to Disable Icemaker when Planning to Take Ice
PFE24HML	3-door Bottom Freezer	33"	Shabbos Keeper	Required to Disable Icemaker when Planning to Take Ice
PFE24HSL	3-door Bottom Freezer	33"	Shabbos Keeper	Required to Disable Icemaker when Planning to Take Ice
PFE24HYR	3-door Bottom Freezer	33"	Shabbos Keeper	Required to Disable Icemaker when Planning to Take Ice
PFE24JGK	3-door Bottom Freezer	33"	Shabbos Keeper	Required to Disable Icemaker when Planning to Take Ice
PFE24JMK	3-door Bottom Freezer	33"	Shabbos Keeper	Required to Disable Icemaker when Planning to Take Ice
PFE24JSK	3-door Bottom Freezer	33"	Shabbos Keeper	Required to Disable Icemaker when Planning to Take Ice
PFE28KBL	3-door Bottom Freezer	36"	Shabbos Keeper	Automatically Disabled with Shabbos Keeper
PFE28KEL	3-door Bottom Freezer	36"	Shabbos Keeper	Automatically Disabled with Shabbos Keeper
PFE28KMK	3-door Bottom Freezer	36"	Shabbos Keeper	Automatically Disabled with Shabbos Keeper
PFE28KSK	3-door Bottom Freezer	36"	Shabbos Keeper	Automatically Disabled with Shabbos Keeper
PFE28KYN	3-door Bottom Freezer	36"	Shabbos Keeper	Automatically Disabled with Shabbos Keeper
PFE28PBL	3-door Bottom Freezer	36"	Shabbos Keeper	Automatically Disabled with Shabbos Keeper
PFE28PEL	3-door Bottom Freezer	36"	Shabbos Keeper	Automatically Disabled with Shabbos Keeper

Model Number:	Product Type:	Width:	How can this fridge be used on Shabbos?	Ice maker Deactivation Status
PFE28PMK	3-door Bottom Freezer	36"	Shabbos Keeper	Automatically Disabled with Shabbos Keeper
PFE28PSK	3-door Bottom Freezer	36"	Shabbos Keeper	Automatically Disabled with Shabbos Keeper
PFE28PYN	3-door Bottom Freezer	36"	Shabbos Keeper	Automatically Disabled with Shabbos Keeper
PNE21KGK	3-door Bottom Freezer	30"	Shabbos Keeper	Required to Disable Icemaker
PNE21KMK	3-door Bottom Freezer	30"	Shabbos Keeper	Required to Disable Icemaker
PNE21KSK	3-door Bottom Freezer	30"	Shabbos Keeper	Required to Disable Icemaker
PNE21NGL	3-door Bottom Freezer	30"	Shabbos Keeper	Required to Disable Icemaker
PNE21NML	3-door Bottom Freezer	30"	Shabbos Keeper	Required to Disable Icemaker
PNE21NSL	3-door Bottom Freezer	30"	Shabbos Keeper	Required to Disable Icemaker
PNE21NYR	3-door Bottom Freezer	30"	Shabbos Keeper	Required to Disable Icemaker
PNE25JGK	3-door Bottom Freezer	33"	Shabbos Keeper	Required to Disable Icemaker
PNE25JMK	3-door Bottom Freezer	33"	Shabbos Keeper	Required to Disable Icemaker
PNE25JSK	3-door Bottom Freezer	33"	Shabbos Keeper	Required to Disable Icemaker
PNE25NGL	3-door Bottom Freezer	33"	Shabbos Keeper	Required to Disable Icemaker
PNE25NML	3-door Bottom Freezer	33"	Shabbos Keeper	Required to Disable Icemaker
PNE25NSL	3-door Bottom Freezer	33"	Shabbos Keeper	Required to Disable Icemaker
PNE25NYR	3-door Bottom Freezer	33"	Shabbos Keeper	Required to Disable Icemaker

Model Number:	Product Type:	Width:	How can this fridge be used on Shabbos?	Ice maker Deactivation Status
PWE23KEL	3-door Bottom Freezer	36"	Shabbos Keeper	Automatically Disabled with Shabbos Keeper
PWE23KMK	3-door Bottom Freezer	36"	Shabbos Keeper	Automatically Disabled with Shabbos Keeper
PWE23KSK	3-door Bottom Freezer	36"	Shabbos Keeper	Automatically Disabled with Shabbos Keeper
PWE23KYN	3-door Bottom Freezer	36"	Shabbos Keeper	Automatically Disabled with Shabbos Keeper
PWE23SWN	3-door Bottom Freezer	36"	Shabbos Keeper	Automatically Disabled with Shabbos Keeper
PYD22KBL	3-door Bottom Freezer	36"	Shabbos Keeper	Automatically Disabled with Shabbos Keeper
PYD22KEL	3-door Bottom Freezer	36"	Shabbos Keeper	Automatically Disabled with Shabbos Keeper
PYD22KSL	3-door Bottom Freezer	36"	Shabbos Keeper	Automatically Disabled with Shabbos Keeper
PYD22KYN	3-door Bottom Freezer	36"	Shabbos Keeper	Automatically Disabled with Shabbos Keeper
PYE18HBL	3-door Bottom Freezer	33"	Shabbos Keeper	Required to Disable Icemaker when Planning to Take Ice
PYE18HEM	3-door Bottom Freezer	33"	Shabbos Keeper	Required to Disable Icemaker when Planning to Take Ice
PYE18HML	3-door Bottom Freezer	33"	Shabbos Keeper	Required to Disable Icemaker when Planning to Take Ice
PYE18HSL	3-door Bottom Freezer	33"	Shabbos Keeper	Required to Disable Icemaker when Planning to Take Ice
PYE18HYR	3-door Bottom Freezer	33"	Shabbos Keeper	Required to Disable Icemaker when Planning to Take Ice
PYE22KBL	3-door Bottom Freezer	36"	Shabbos Keeper	Automatically Disabled with Shabbos Keeper

Model Number:	Product Type:	Width:	How can this fridge be used on Shabbos?	Ice maker Deactivation Status
PYE22KEL	3-door Bottom Freezer	36"	Shabbos Keeper	Automatically Disabled with Shabbos Keeper
PYE22KMK	3-door Bottom Freezer	36"	Shabbos Keeper	Automatically Disabled with Shabbos Keeper
PYE22KSK	3-door Bottom Freezer	36"	Shabbos Keeper	Automatically Disabled with Shabbos Keeper
PYE22KYN	3-door Bottom Freezer	36"	Shabbos Keeper	Automatically Disabled with Shabbos Keeper
PYE22PBL	3-door Bottom Freezer	36"	Shabbos Keeper	Automatically Disabled with Shabbos Keeper
PYE22PEL	3-door Bottom Freezer	36"	Shabbos Keeper	Automatically Disabled with Shabbos Keeper
PYE22PMK	3-door Bottom Freezer	36"	Shabbos Keeper	Automatically Disabled with Shabbos Keeper
PYE22PSK	3-door Bottom Freezer	36"	Shabbos Keeper	Automatically Disabled with Shabbos Keeper
PYE22PYN	3-door Bottom Freezer	36"	Shabbos Keeper	Automatically Disabled with Shabbos Keeper
QNE27JBM	3-door Bottom Freezer	36"	Shabbos Keeper	Required to Disable Icemaker
QNE27JSM	3-door Bottom Freezer	36"	Shabbos Keeper	Required to Disable Icemaker
QNE27JYM	3-door Bottom Freezer	36"	Shabbos Keeper	Required to Disable Icemaker
ZWE23ESH	3-door Bottom Freezer	36"	Shabbos Keeper	Automatically Disabled with Shabbos Keeper
ZWE23ESN	3-door Bottom Freezer	36"	Shabbos Keeper	Automatically Disabled with Shabbos Keeper
ZWE23NST	3-door Bottom Freezer	36"	Shabbos Keeper	Automatically Disabled with Shabbos Keeper
ZWE23NSY	3-door Bottom Freezer	36"	Shabbos Keeper	Automatically Disabled with Shabbos Keeper
ZWE23PSH	3-door Bottom Freezer	36"	Shabbos Keeper	Automatically Disabled with Shabbos Keeper

Model Number:	Product Type:	Width:	How can this fridge be used on Shabbos?	Ice maker Deactivation Status
ZWE23PSN	3-door Bottom Freezer	36"	Shabbos Keeper	Automatically Disabled with Shabbos Keeper
CGE29DM5	4-door Bottom Freezer	36"	Shabbos Keeper	Automatically Disabled with Shabbos Keeper
CGE29DP2	4-door Bottom Freezer	36"	Shabbos Keeper	Automatically Disabled with Shabbos Keeper
CGE29DP3	4-door Bottom Freezer	36"	Shabbos Keeper	Automatically Disabled with Shabbos Keeper
CGE29DP4	4-door Bottom Freezer	36"	Shabbos Keeper	Automatically Disabled with Shabbos Keeper
CJE23DM5	4-door Bottom Freezer	36"	Shabbos Keeper	Automatically Disabled with Shabbos Keeper
CJE23DP2	4-door Bottom Freezer	36"	Shabbos Keeper	Automatically Disabled with Shabbos Keeper
CJE23DP3	4-door Bottom Freezer	36"	Shabbos Keeper	Automatically Disabled with Shabbos Keeper
CJE23DP4	4-door Bottom Freezer	36"	Shabbos Keeper	Automatically Disabled with Shabbos Keeper
CVE28DM5	4-door Bottom Freezer	36"	Shabbos Keeper	Automatically Disabled with Shabbos Keeper
CVE28DP2	4-door Bottom Freezer	36"	Shabbos Keeper	Automatically Disabled with Shabbos Keeper
CVE28DP3	4-door Bottom Freezer	36"	Shabbos Keeper	Automatically Disabled with Shabbos Keeper
CVE28DP4	4-door Bottom Freezer	36"	Shabbos Keeper	Automatically Disabled with Shabbos Keeper
CXE22DM5	4-door Bottom Freezer	36"	Shabbos Keeper	Automatically Disabled with Shabbos Keeper
CXE22DP2	4-door Bottom Freezer	36"	Shabbos Keeper	Automatically Disabled with Shabbos Keeper
CXE22DP3	4-door Bottom Freezer	36"	Shabbos Keeper	Automatically Disabled with Shabbos Keeper
CXE22DP4	4-door Bottom Freezer	36"	Shabbos Keeper	Automatically Disabled with Shabbos Keeper

Model Number:	Product Type:	Width:	How can this fridge be used on Shabbos?	Ice maker Deactivation Status
PGD29BYT	4-door Bottom Freezer	36"	Shabbos Keeper	Automatically Disabled with Shabbos Keeper
PGE29BYT	4-door Bottom Freezer	36"	Shabbos Keeper	Automatically Disabled with Shabbos Keeper
PJD23BYW	4-door Bottom Freezer	36"	Shabbos Keeper	Automatically Disabled with Shabbos Keeper
PJE23BYW	4-door Bottom Freezer	36"	Shabbos Keeper	Automatically Disabled with Shabbos Keeper
PVD28BYN	4-door Bottom Freezer	36"	Shabbos Keeper	Automatically Disabled with Shabbos Keeper
PVD28HYY	4-door Bottom Freezer	36"	Shabbos Keeper	Automatically Disabled with Shabbos Keeper
PXD22BYP	4-door Bottom Freezer	36"	Shabbos Keeper	Automatically Disabled with Shabbos Keeper
PXD22HYY	4-door Bottom Freezer	36"	Shabbos Keeper	Automatically Disabled with Shabbos Keeper
CSB42WP2N	Built-in Side-by-Side	42"	Shabbos Keeper	Required to Disable Icemaker when Planning to Take Ice
CSB42WP2R	Built-in Side-by-Side	42"	Shabbos Keeper	Required to Disable Icemaker when Planning to Take Ice
CSB42YP2N	Built-in Side-by-Side	42"	Shabbos Keeper	Required to Disable Icemaker when Planning to Take Ice
CSB42YP2R	Built-in Side-by-Side	42"	Shabbos Keeper	Required to Disable Icemaker when Planning to Take Ice
CSB48WP2N	Built-in Side-by-Side	48"	Shabbos Keeper	Required to Disable Icemaker when Planning to Take Ice
CSB48WP2R	Built-in Side-by-Side	48"	Shabbos Keeper	Required to Disable Icemaker when Planning to Take Ice

Model Number:	Product Type:	Width:	How can this fridge be used on Shabbos?	Ice maker Deactivation Status
CSB48YP2N	Built-in Side-by-Side	48"	Shabbos Keeper	Required to Disable Icemaker when Planning to Take Ice
CSB48YP2R	Built-in Side-by-Side	48"	Shabbos Keeper	Required to Disable Icemaker when Planning to Take Ice
PSB42YSN	Built-in Side-by-Side	42"	Shabbos Keeper	Required to Disable Icemaker when Planning to Take Ice
PSB42YSR	Built-in Side-by-Side	42"	Shabbos Keeper	Required to Disable Icemaker when Planning to Take Ice
PSB48YSN	Built-in Side-by-Side	48"	Shabbos Keeper	Required to Disable Icemaker when Planning to Take Ice
PSB48YSR	Built-in Side-by-Side	48"	Shabbos Keeper	Required to Disable Icemaker when Planning to Take Ice
ZIS420NN	Built-in Side-by-Side	42"	Shabbos Keeper	Required to Disable Icemaker when Planning to Take Ice
ZIS420NP	Built-in Side-by-Side	42"	Shabbos Keeper	Required to Disable Icemaker when Planning to Take Ice
ZIS480NN	Built-in Side-by-Side	48"	Shabbos Keeper	Required to Disable Icemaker when Planning to Take Ice
ZIS480NP	Built-in Side-by-Side	48"	Shabbos Keeper	Required to Disable Icemaker when Planning to Take Ice
ZISB360DN	Built-in Side-by-Side	36"	Shabbos Keeper	Required to Disable Icemaker when Planning to Take Ice
ZISB360DP	Built-in Side-by-Side	36"	Shabbos Keeper	Required to Disable Icemaker when Planning to Take Ice

Model Number:	Product Type:	Width:	How can this fridge be used on Shabbos?	Ice maker Deactivation Status
ZISB420DN	Built-in Side-by-Side	42"	Shabbos Keeper	Required to Disable Icemaker when Planning to Take Ice
ZISB420DP	Built-in Side-by-Side	42"	Shabbos Keeper	Required to Disable Icemaker when Planning to Take Ice
ZISB480DN	Built-in Side-by-Side	48"	Shabbos Keeper	Required to Disable Icemaker when Planning to Take Ice
ZISB480DP	Built-in Side-by-Side	48"	Shabbos Keeper	Required to Disable Icemaker when Planning to Take Ice
ZISP420DN	Built-in Side-by-Side	42"	Shabbos Keeper	Required to Disable Icemaker when Planning to Take Ice
ZISP480DN	Built-in Side-by-Side	48"	Shabbos Keeper	Required to Disable Icemaker when Planning to Take Ice
ZISS360DN	Built-in Side-by-Side	36"	Shabbos Keeper	Required to Disable Icemaker when Planning to Take Ice
ZISS360DP	Built-in Side-by-Side	36"	Shabbos Keeper	Required to Disable Icemaker when Planning to Take Ice
ZISS420DN	Built-in Side-by-Side	42"	Shabbos Keeper	Required to Disable Icemaker when Planning to Take Ice
ZISS420DP	Built-in Side-by-Side	42"	Shabbos Keeper	Required to Disable Icemaker when Planning to Take Ice
ZISS420NN	Built-in Side-by-Side	42"	Shabbos Keeper	Required to Disable Icemaker when Planning to Take Ice
ZISS420NP	Built-in Side-by-Side	42"	Shabbos Keeper	Required to Disable Ice maker when planning to Take Ice

Model Number:	Product Type:	Width:	How can this fridge be used on Shabbos?	Ice maker Deactivation Status
ZISS480DN	Built-in Side-by-Side	48"	Shabbos Keeper	Required to Disable Icemaker when Planning to Take Ice
ZISS480DP	Built-in Side-by-Side	48"	Shabbos Keeper	Required to Disable Icemaker when Planning to Take Ice
ZISS480NN	Built-in Side-by-Side	48"	Shabbos Keeper	Required to Disable Icemaker when Planning to Take Ice
ZISS480NP	Built-in Side-by-Side	48"	Shabbos Keeper	Required to Disable Ice maker when planning to Take Ice
ZIF181NBR	Columns	18"	Shabbos Keeper	Automatically Disabled with Shabbos Keeper
ZIF181NPP	Columns	18"	Shabbos Keeper	Automatically Disabled with Shabbos Keeper
ZIF241NBR	Columns	24"	Shabbos Keeper	Automatically Disabled with Shabbos Keeper
ZIF241NPP	Columns	24"	Shabbos Keeper	Automatically Disabled with Shabbos Keeper
ZIF301NBR	Columns	30"	Shabbos Keeper	Automatically Disabled with Shabbos Keeper
ZIF301NPP	Columns	30"	Shabbos Keeper	Automatically Disabled with Shabbos Keeper
ZIF361NBR	Columns	36"	Shabbos Keeper	Automatically Disabled with Shabbos Keeper
ZIF361NPR	Columns	36"	Shabbos Keeper	Automatically Disabled with Shabbos Keeper
ZIR241NBR	Columns	24"	Shabbos Keeper	Automatically Disabled with Shabbos Keeper
ZIR241NPP	Columns	24"	Shabbos Keeper	Automatically Disabled with Shabbos Keeper
ZIR301NBR	Columns	30"	Shabbos Keeper	Automatically Disabled with Shabbos Keeper

Model Number:	Product Type:	Width:	How can this fridge be used on Shabbos?	Ice maker Deactivation Status
ZIR301NPP	Columns	30"	Shabbos Keeper	Automatically Disabled with Shabbos Keeper
ZIR361NBR	Columns	36"	Shabbos Keeper	Automatically Disabled with Shabbos Keeper
ZIR361NPR	Columns	36"	Shabbos Keeper	Automatically Disabled with Shabbos Keeper
CIC36LP2V	Integrated Bottom Freezer	36"	Shabbos Keeper	Automatically Disabled with Shabbos Keeper
CIC36RP2V	Integrated Bottom Freezer	36"	Shabbos Keeper	Automatically Disabled with Shabbos Keeper
CIP36NP2V	Integrated Bottom Freezer	36"	Shabbos Keeper	Automatically Disabled with Shabbos Keeper
ZIC363IPV	Integrated Bottom Freezer	36"	Shabbos Keeper	Automatically Disabled with Shabbos Keeper
ZIC363NBV	Integrated Bottom Freezer	36"	Shabbos Keeper	Automatically Disabled with Shabbos Keeper
ZIP364IPV	Integrated Bottom Freezer	36"	Shabbos Keeper	Automatically Disabled with Shabbos Keeper
ZIP364NBV	Integrated Bottom Freezer	36"	Shabbos Keeper	Automatically Disabled with Shabbos Keeper
CAE28DM5	Quad Door Bottom Freezer	36"	Shabbos Keeper	Automatically Disabled with Shabbos Keeper
CHE23DM5	Quad Door Bottom Freezer	36"	Shabbos Keeper	Automatically Disabled with Shabbos Keeper
PAD28BYT	Quad Door Bottom Freezer	36"	Shabbos Keeper	Automatically Disabled with Shabbos Keeper
PAE28BYT	Quad Door Bottom Freezer	36"	Shabbos Keeper	Automatically Disabled with Shabbos Keeper
PHD23BYW	Quad Door Bottom Freezer	36"	Shabbos Keeper	Automatically Disabled with Shabbos Keeper

Model Number:	Product Type:	Width:	How can this fridge be used on Shabbos?	Ice maker Deactivation Status
CZS22MP2	Side-by-Side	36"	Shabbos Keeper	Required to Disable Icemaker when Planning to Take Ice
GKS24NYY	Side-by-Side	36"	Shabbos Keeper	Automatically Disabled with Shabbos Keeper
GOS29NYY	Side-by-Side	36"	Shabbos Keeper	Automatically Disabled with Shabbos Keeper
GSE23GGP	Side-by-Side	33"	Shabbos Keeper	Required to Disable Icemaker when Planning to Take Ice
GSE23GSP	Side-by-Side	33"	Shabbos Keeper	Required to Disable Icemaker when Planning to Take Ice
GSE23GYP	Side-by-Side	33"	Shabbos Keeper	Required to Disable Icemaker when Planning to Take Ice
GSE25GGP	Side-by-Side	36"	Shabbos Keeper	Required to Disable Ice maker when planning to Take Ice
GSE25GSP	Side By Side	36"	Shabbos Keeper	Required to disable ice maker when planning to Take Ice
GSE25GYP	Side-by-Side	36"	Shabbos Keeper	Required to disable ice maker when planning to Take Ice
GSS23GGP	Side-by-Side	33"	Shabbos Keeper	Required to Disable Icemaker when Planning to Take Ice
GSS23GMP	Side-by-Side	33"	Shabbos Keeper	Required to Disable Icemaker when Planning to Take Ice
GSS23GYP	Side-by-Side	33"	Shabbos Keeper	Required to Disable Icemaker when Planning to Take Ice
GSS25GGP	Side-by-Side	36"	Shabbos Keeper	Required to disable ice maker when planning to Take Ice

Model Number:	Product Type:	Width:	How can this fridge be used on Shabbos?	Ice maker Deactivation Status
GSS25GMP	Side-by-Side	36"	Shabbos Keeper	Required to Disable Icemaker when Planning to Take Ice
GSE28NYY	Side-by-Side	36"	Shabbos Keeper	Automatically Disabled with Shabbos Keeper
GSS25GYP	Side-by-Side	36"	Shabbos Keeper	Required to disable ice maker when planning to Take Ice
GSS25IBN	Side-by-Side	36"	Shabbos Keeper	Required to disable ice maker when planning to Take Ice
GSS25IEN	Side-by-Side	36"	Shabbos Keeper	Required to Disable Icemaker when Planning to Take Ice
GSS25IGN	Side-by-Side	36"	Shabbos Keeper	Required to Disable Icemaker when Planning to Take Ice
GSS25IMN	Side-by-Side	36"	Shabbos Keeper	Required to Disable Icemaker when Planning to Take Ice
GSS25IYN	Side-by-Side	36"	Shabbos Keeper	Required to Disable Icemaker when Planning to Take Ice
GSE28NGY	Side-by-Side	36"	Shabbos Keeper	Automatically Disabled with Shabbos Keeper
GSS28HYY	Side-by-Side	36"	Shabbos Keeper	Automatically Disabled with Shabbos Keeper
GSS28LYY	Side-by-Side	36"	Shabbos Keeper	Automatically Disabled with Shabbos Keeper
GSS28NYY	Side-by-Side	36"	Shabbos Keeper	Automatically Disabled with Shabbos Keeper
GSS28PYY	Side-by-Side	36"	Shabbos Keeper	Automatically Disabled with Shabbos Keeper
GZE24NGY	Side-by-Side	36"	Shabbos Keeper	Automatically Disabled with Shabbos Keeper

Model Number:	Product Type:	Width:	How can this fridge be used on Shabbos?	Ice maker Deactivation Status
GZE24NYY	Side-by-Side	36"	Shabbos Keeper	Automatically Disabled with Shabbos Keeper
GZS22IEN	Side-by-Side	36"	Shabbos Keeper	Required to Disable Icemaker when Planning to Take Ice
GZS22IMN	Side-by-Side	36"	Shabbos Keeper	Required to Disable Icemaker when Planning to Take Ice
GZS22IYN	Side-by-Side	36"	Shabbos Keeper	Required to Disable Icemaker when Planning to Take Ice
GZS24NGY	Side-by-Side	36"	Shabbos Keeper	Automatically Disabled with Shabbos Keeper
GZS24NMY	Side-by-Side	36"	Shabbos Keeper	Automatically Disabled with Shabbos Keeper
GZS24NYY	Side-by-Side	36"	Shabbos Keeper	Automatically Disabled with Shabbos Keeper
GZS24PYY	Side-by-Side	36"	Shabbos Keeper	Automatically Disabled with Shabbos Keeper
PSE25KYH	Side-by-Side	36"	Shabbos Keeper	Required to Disable Icemaker when Planning to Take Ice
PSS28KYH	Side-by-Side	36"	Shabbos Keeper	Required to Disable Icemaker when Planning to Take Ice
PZS22MYK	Side-by-Side	36"	Shabbos Keeper	Required to Disable Icemaker when Planning to Take Ice
CSB42WP2N	Built-in Side-by-Side	42"	Shabbos Keeper	Required to Disable Icemaker when Planning to Take Ice
CSB48WP2N	Built-in Side-by-Side	48"	Shabbos Keeper	Required to Disable Icemaker when Planning to Take Ice
GSS28NGY	Side-by-Side	36"	Shabbos Keeper	Automatically Disabled with Shabbos Keeper

Model Number:	Product Type:	Width:	How can this fridge be used on Shabbos?	Ice maker Deactivation Status
PSE28QYY	Side-by-Side	36”	Shabbos Keeper	Automatically Disabled with Shabbos Keeper
POE29QYY	Side-by-Side	36”	Shabbos Keeper	Automatically Disabled with Shabbos Keeper
PZE24QYY	Side-by-Side	36”	Shabbos Keeper	Automatically Disabled with Shabbos Keeper
PKE24QYY	Side-by-Side	36”	Shabbos Keeper	Automatically Disabled with Shabbos Keeper
CZE24RP2Y	Sise-by-Side	36”	Shabbos Keeper	Automatically Disabled with Shabbos Keeper
CZE24RP3Y	Sise-by-Side	36”	Shabbos Keeper	Automatically Disabled with Shabbos Keeper
CZE24RP4Y	Sise-by-Side	36”	Shabbos Keeper	Automatically Disabled with Shabbos Keeper
CKE24RP2Y	Sise-by-Side	36”	Shabbos Keeper	Automatically Disabled with Shabbos Keeper
CKE24RP3Y	Sise-by-Side	36”	Shabbos Keeper	Automatically Disabled with Shabbos Keeper
CKE24RP4Y	Sise-by-Side	36”	Shabbos Keeper	Automatically Disabled with Shabbos Keeper
GIE17GSN*	Top Freezer	28"	Manual	Required to Disable Icemaker when Planning to Take Ice
GIE18DTN*	Top Freezer	28"	Manual	Required to Disable Icemaker when Planning to Take Ice
GIE18GCN*	Top Freezer	28"	Manual	Required to Disable Icemaker when Planning to Take Ice
GIE18GSN*	Top Freezer	28"	Manual	Required to Disable Icemaker when Planning to Take Ice
GIE18GTN*	Top Freezer	28"	Manual	Required to Disable Icemaker when Planning to Take Ice

Model Number:	Product Type:	Width:	How can this fridge be used on Shabbos?	Ice maker Deactivation Status
GIE19JSN*	Top Freezer	30"	Manual	Required to Disable Icemaker when Planning to Take Ice
GIE22JMN*	Top Freezer	33"	Manual	Required to Disable Icemaker when Planning to Take Ice
GIE22JSN*	Top Freezer	33"	Manual	Required to Disable Icemaker when Planning to Take Ice
GIE22JTN*	Top Freezer	33"	Manual	Required to Disable Icemaker when Planning to Take Ice
GPE17CTN*	Top Freezer	28"	Manual	Required to Disable Icemaker when Planning to Take Ice
GTE16DTN*	Top Freezer	28"	Manual	Required to Disable Icemaker when Planning to Take Ice
GTE16GTN*	Top Freezer	28"	Manual	Required to Disable Icemaker when Planning to Take Ice
GTE17DTN*	Top Freezer	28"	Manual	Required to Disable Icemaker when Planning to Take Ice
GTE17GSN*	Top Freezer	28"	Manual	Required to Disable Icemaker when Planning to Take Ice
GTE17GTN*	Top Freezer	28"	Manual	Required to Disable Icemaker when Planning to Take Ice
GTE18DCN*	Top Freezer	28"	Manual	Required to Disable Icemaker when Planning to Take Ice
GTE18DTN*	Top Freezer	28"	Manual	Required to Disable Icemaker when Planning to Take Ice

Model Number:	Product Type:	Width:	How can this fridge be used on Shabbos?	Ice maker Deactivation Status
GTE18GMN*	Top Freezer	28"	Manual	Required to Disable Icemaker when Planning to Take Ice
GTE18GSN*	Top Freezer	28"	Manual	Required to Disable Icemaker when Planning to Take Ice
GTE18GTN*	Top Freezer	28"	Manual	Required to Disable Icemaker when Planning to Take Ice
GTE19DTN*	Top Freezer	30"	Manual	Required to Disable Icemaker when Planning to Take Ice
GTE19JSN*	Top Freezer	30"	Manual	Required to Disable Icemaker when Planning to Take Ice
GTE19JTN*	Top Freezer	30"	Manual	Required to Disable Icemaker when Planning to Take Ice
GTE22JMN*	Top Freezer	33"	Manual	Required to Disable Icemaker when Planning to Take Ice
GTE22JSN*	Top Freezer	33"	Manual	Required to Disable Icemaker when Planning to Take Ice
GTE22JTN*	Top Freezer	33"	Manual	Required to Disable Icemaker when Planning to Take Ice
GTS16DTN*	Top Freezer	28"	Manual	Required to Disable Icemaker when Planning to Take Ice
GTS17DTN*	Top Freezer	28"	Manual	Required to Disable Icemaker when Planning to Take Ice
GTS17GSN*	Top Freezer	28"	Manual	Required to Disable Icemaker when Planning to Take Ice

Model Number:	Product Type:	Width:	How can this fridge be used on Shabbos?	Ice maker Deactivation Status
GTS17GTN*	Top Freezer	28"	Manual	Required to Disable Icemaker when Planning to Take Ice
GTS18DTN*	Top Freezer	28"	Manual	Required to Disable Icemaker when Planning to Take Ice
GTS18GSN*	Top Freezer	28"	Manual	Required to Disable Icemaker when Planning to Take Ice
GTS18GTN*	Top Freezer	28"	Manual	Required to Disable Ice maker when planning to Take Ice
GTS18HGN*	Top Freezer	28"	Manual	Required to Disable Ice maker when planning to Take Ice
GTS18HMN*	Top Freezer	28"	Manual	Required to Disable Ice maker when planning to Take Ice
GTS18HSN*	Top Freezer	28"	Manual	Required to Disable Icemaker when Planning to Take Ice
GTS18HYN*	Top Freezer	28"	Manual	Required to Disable Icemaker when Planning to Take Ice
GTS19KGN*	Top Freezer	30"	Manual	Required to Disable Icemaker when Planning to Take Ice
GTS19KMN*	Top Freezer	30"	Manual	Required to Disable Ice maker when Planning to Take Ice
GTS19KSN*	Top Freezer	30"	Manual	Required to Disable Ice maker when Planning to Take Ice
GTS19KYN*	Top Freezer	30"	Manual	Required to disable ice maker when planning to Take Ice

Model Number:	Product Type:	Width:	How can this fridge be used on Shabbos?	Ice maker Deactivation Status
GTS22KGN*	Top Freezer	33"	Manual	Required to Disable Icemaker when Planning to Take Ice
GTS22KMN*	Top Freezer	33"	Manual	Required to Disable Icemaker when Planning to Take Ice
GTS22KSN*	Top Freezer	33"	Manual	Required to Disable Icemaker when Planning to Take Ice
GTS22KYN*	Top Freezer	33"	Manual	Required to Disable Icemaker when Planning to Take Ice
HPE16BTN*	Top Freezer	28"	Manual	Required to Disable Icemaker when Planning to Take Ice
HPS16BTN*	Top Freezer	28"	Manual	Required to Disable Icemaker when Planning to Take Ice
HPS18BGN*	Top Freezer	28"	Manual	Required to Disable Icemaker when Planning to Take Ice
HPS18BTN*	Top Freezer	28"	Manual	Required to Disable Icemaker when Planning to Take Ice
XRE18GGA*	Top Freezer	28"	Manual	Required to Disable Icemaker when Planning to Take Ice
XRS16BGA*	Top Freezer	28"	Manual	Required to Disable Icemaker when Planning to Take Ice
XRS18GGA*	Top Freezer	28"	Manual	Required to disable ice maker when planning to take ice
XRS22KGA*	Top Freezer	33"	Manual	Required to Disable Ice maker when planning to Take Ice